

名称	OUTCHAIR-Q100 英文说明书-v1.0		
规格	90x127mm	其它	
比列	1:1	材质	80g双胶纸
要求	彩色单面印刷 折页		
备注	± 误差控制1mm 以内		
设计	刘世珍	审核	批准
日期	20191030	日期	日期

90mm

127mm

Q100 User Manual

Feature

- 3.7V/10000mAh battery capacity
- 10.5W fast charging (input & output)
- Dual USB-A output
- Micro USB & Type C input
- Over charge/over discharge/over voltage/over current/over temperature/load short circuiting and EMI protect.
- V0 fire resistant material
- CE/FCC certified

Product appearance



Specification

Model	Q100	Capacity	3.7V/10000mAh
Weight	~205g	Size	90(L)*63(W)*22.1(H)mm
Input port	Micro USB & Type C	Output port	USB-A x2
Input	DC 5V/2.1A	Output	DC 5V/2.1A (Total)
Charging time	5V/2.1A About 5h	Output capacity	~6350mAh (5V/TYP 2.1A)
Work temperature	0°C~40°C	Storage temperature	-10°C~50°C

Electric quantity indication

LED	LED indication	Power Level
LED 1	All lights on	75~100%
LED 2	The 1 st , 2 nd , 3 rd lights on	50~75%
LED 4	The 1 st , 2 nd lights on	25~50%
LED 3	The 1 st light on	5~25%

Notes:

1. Press the switch button then the LED light is on. The power bank will be automatically off if no devices are connected for a short time.
2. Press the switch button, if the remaining power is under 5%, the LED light will keep blinking, indicating the power bank need to be charged.

Usage:

Use the Power Bank to operate Outchair's heated products or to charge smartphone or digital products. (DC 5V)

Charge the Power Bank:

1. Connect the power bank input port with Micro USB or TYPE-C connector, the corresponding LED lights of power bank flash, which indicates the charge status. When the battery is full, all 4 LED lights are on.
2. Connect the smartphone or digital products with the power bank to charge automatically, the corresponding LED lights are on while charging.

Attentions:

1. Before using the product, please charge it first.
2. Do not place or use the product at high temperature or in humid environment. Do not expose it to the sunlight.
3. It is forbidden to throw the product in fire or water so as to avoid fire and explosion.
4. Please keep the product out of the reach of children.
5. Do not disassemble the device arbitrarily, as no removable/maintainable parts are installed in the product.
6. Do not vigorously shake, hit, or impact the product.
7. If the product has exposed liquid, heave or other abnormalities, please do not continue to use, and contact customer service center.
8. If the product has liquid leakage and splashes into the eyes, do not knead your eyes, wash with clean water immediately, and go to the hospital for medical treatment.
9. It is normal that the temperature of the product rises during working; please take out of the product during or after use.
10. Do not cover or block the product with paper or other objects, to avoid blocking the heat dissipation and cold cutting.
11. Do not use the product if nobody watches it in the car or somewhere.
12. Before using the product, please check its voltage demand so as to prevent it being damaged by wrong voltage or watt.
13. If the mobile power supply is not used for long time, please charge/discharge it once every three months to ensure the service life of the product.
14. When using the product and after complete discharging, please fully charge the product to supply the power for digital product at any time.

Unsere hochwertige 5V Lithium Polymer Powerbank liefert je nach eingestellter Heizstufe für bis zu 6 Stunden Energie. Die Polymer-Powerbank hat gegenüber gängigen Ionen-Powerbanks den Vorteil, dass sie sehr viel leistungsstärker und langlebiger ist. Diese Powerbank verfügt über zwei 5V USB-Ausgänge sowie einen Micro USB-Ausgang um sie gleichzeitig für das Laden anderer Geräte nutzen zu können. Die Powerbank hat eine Lebensdauer von mindestens 400 Ladezyklen, die Garantie beträgt 1 Jahr.

Die Powerbank wird von Werk aus halb geladen geliefert. Dennoch empfehlen wir, vor dem ersten Gebrauch die Powerbank einmal vollständig laden zu lassen.
Bedienungshinweise:

1. Die Powerbank muss nicht separat eingeschaltet werden. Verbinden Sie diese mit dem dafür vorgesehenen Stecker in der Tasche.
2. Auf/in der Tasche befindet sich der Einschaltknopf. Drücken Sie den On-Button für 3 Sekunden. Das Produkt ist nun aktiv und heizt auf voller Leistung (Farbe Rot leuchtet durchgehend).
3. Das Produkt hat 3 Heizstufen, die durch jeweils kurzes Drücken des On-Buttons eingestellt werden können. Die Stufen sind farblich zu erkennen. Rot = höchste Heizstufe, Grün = mittlere Heizstufe und Blau = niedrigste Heizstufe.
4. Um das Produkt auszuschalten drücken Sie den Powerbutton wieder für 3 Sekunden. Die Powerbank muss nicht separat ausgeschaltet werden.

Damit eine volle Ladung garantiert ist, muss die Powerbank vor dem erstmaligen Gebrauch bzw. nach längerer Nichtbenutzung vollständig aufgeladen werden. Die Powerbank sollte in jedem Fall mindestens 1 Mal alle 6 Monate aufgeladen werden um ihre Kapazität zu erhalten.

! Decken Sie die Powerbank während des Ladevorgangs nicht durch Decken, Kissen oder Ähnliches ab.

! HINWEIS ! : Bitte beachten Sie die Sicherheitshinweise in der Bedienungsanleitung

CE, FCC, RoHS, WEEE zertifiziert